

Raised Fixings - Fitting Instructions

Package Contents:

- 4 x Satin Anodised Aluminium Barrels
- 4 x Satin Anodised Aluminium Threaded Heads
- 4 x Black Wood Screws



- 1) Position the nameplate/plaque in location and make a surface mark/spot to where the holes need to be positioned (through the existing holes on the plaque)

Drill a suitable size hole to where each spot mark was made.
NB the size of hole will depend on the type of surface you are fixing the nameplate to and whether any wall plugs are required.



- 2) Place each of the black screws into a barrel, ensuring that the thread protrudes out of the barrel end.



- 3) With the screws still positioned inside the barrel, using a flat head screw driver carefully screw each one into the 4 x pilot holes in the wall/door. The barrels should now remain fixed in location.



- 4) Position the nameplate up against the fixed barrels and one by one push each of the 4 silver threaded bolt heads through the hole in the nameplate.

Gently twist the bolt head so that the thread tightens into the barrel.
You may need to hold the barrel with your free hand to prevent the barrel from turning



- 5) Once this has been completed for all four heads, your nameplate will be fixed in location and protrude away from the wall/door as shown

